



## KIT INSTRUCTIONS

**BEFORE HANDLING OR APPLYING ANY PRODUCT, READ THE **SAFETY DATA SHEET**. WEAR SAFETY GLASSES AND GLOVES WHILE HANDLING KITS.**

### FOR BEST RESULTS:

CONDITION KITS TO  $\geq 60^{\circ}\text{F}$  ( $15^{\circ}\text{C}$ ) BEFORE USING.  
KITS ARE DESIGNED FOR SINGLE USE. DO NOT DIVIDE.

1. USE 'EGGBEATER' STYLE MIXER WITH A DRILL CAPABLE OF  $\geq 400$  RPM.
2. OPEN KIT AND REMOVE PACKAGED MATERIALS. LEAVE AGGREGATE IN BUCKET.
3. OPEN "PART A" PACKAGE AND POUR INTO AGGREGATE BUCKET. MIX FOR 2 MINUTES.
4. OPEN "PART B" PACKAGE AND POUR INTO BUCKET WITH MIXTURE OF "A" AND AGGREGATE. MIX FOR ADDITIONAL 2 MINUTES. SCRAPE BUCKET SIDES AND BOTTOM WITH PROVIDED SCRAPER.
5. IMMEDIATELY AFTER MIXING, POUR THE MIXED MATERIAL INTO REPAIR AREA. MATERIAL SHOULD BE LEVEL TO SURROUNDING SURFACE.
6. BLACK OR NATURAL TOPPING SAND MAY BE APPLIED TO MATCH SURROUNDING SURFACE. APPLY TOPPING SAND TO REFUSAL WHEN MATERIAL HAS STARTED TO CURE, TYPICALLY AFTER 5-10 MINUTES.

