

**Technical
Data Sheet**



W V C O

Willamette Valley Company

www.wilvaco.com

800.333.9826

Partnering through service,
innovation, and integrity

POLYQuik® Mortar

Fast-Setting Cementitious Polyurethane

DESCRIPTION

POLYQuik® Mortar is a three-component, easy-to-trowel cementitious polyurethane designed for use as a high performance floor coating. It is rigid with a high compression strength, solvent resistance, and thermal shock resistance. POLYQuik® Mortar is used to create a coating from 1/8" to 3/8" thick on concrete floors.

WHERE TO USE

- Concrete Floors
- Commercial Kitchens
- Dairy Plants
- Brewery or Winery
- Restaurants
- Walk-thru autoclaves, etc.

FEATURES AND BENEFITS

- **Rapid Gel Time**– reduces return-to-service time
- **No VOCs**– very low odor
- **Excellent Chemical Resistance**–protects concrete
- **Outstanding Abrasion Resistance**– long lasting
- **Thermal Shock Resistant**– clean with hot steam

PACKAGING

Kit includes 40 lb bags (84kg) with 2 -1 gallon (2-3.78L) containers

COLORS

Gray, Red & Tan

YIELD

Floor Thickness: 1/8 in. or 3.2 mm = 49.5 ft² or 4.6 m²
 1/4 in. or 6.4 mm = 24.7 ft² or 2.3 m²
 3/8 in. or 9.5 mm = 16.5 ft² or 1.5 m²

SHELF LIFE

2 years when properly stored.

STORAGE

Store and ship this product in a clean, dry, low-humidity, shaded or covered environment at 50° to 90° F (10° to 32° C).

TECHNICAL INFORMATION

Typical Properties

VOC , lbs/gal (g/L), ASTM D 2369	0
Viscosity , cps, ASTM D 4878, Mixed	10,420
Density, mixed , lbs/gal	15.06
Service temperature , °F (°C)	-40 to 220 (-40 to 105)
Gel time , min	25
Coefficient of Thermal Expansion , ASTM C 531	3.2E ⁻⁵ in/in/°F
Hardness , Shore D, ASTM 2240	75-80
Return to service , hrs, 70°F (20°C)	6-8
Volume Resistivity , Ω·cm	4.1×10 ¹³
Compressive Strength , psi, ASTM C-579	6,274
Concrete adhesion , psi (MPa), ASTM D 7234 Mode of Failure, Substrate: concrete	772 (5.32) 100% subst.
Abrasive Resistance , mg lost; H18, 1kg, 1k cycles, ASTM D 4060	952

Chemical Resistance

Chemical	Result
Water	No Change (NC)
Coffee	NC
Diesel	NC
HCL (37%)	Slight yellowing
Oil	NC
NaOH (0.83 M)	NC
Ethanol	NC
Acetic Acid (3%)	Slight bleaching
Dish Soap	NC
Acetone	NC

Processing Parameters

Ratio:	Use entire kit. Do not divide.
Application temp. , °F(°C)	45 to 85 (7 to 29)
Equipment	Mechanical mixer, gage rake, trowel

APPLICATION

SURFACE PREPARATION

CONCRETE

1. Concrete should be cured 28 days; for applications on concrete cured less than 28 days seek manufacturer's approval. Concrete must have surface moisture content below 10% (ASTM E 1907), below 12 lbs. per 1000 square feet in a 2 hour period using Calcium Chloride method (ASTM F1869), and less than 92% relative humidity using in situ probe (ASTM F2170).
2. Flooring surfaces must be sound, dry, clean, free of dirt, moisture, loose particles, oil, grease, asphalt, tar, paint, wax, rust, waterproofing and curing or parting compounds, membranes, and other foreign matter (Refer to NACE No. 6/SSPC 13).
3. Clean concrete by abrasive blasting to remove contaminations and laitance while profiling the surface to CSP 4-6 (Refer to ICR Guide 03732).
4. Cut a "key in" around perimeter of floor (3/16" deep and 3/16" wide and 6" from perimeter).
5. Grind any high points and fill any voids with FastPatch. Repeat the above surface preparation steps for all repaired areas.

OTHER SURFACES

1. Remove all old coating material by mechanical means.
2. If sides of floor have absorbed oils, cut away sufficient concrete to ensure a clean, fresh surface.
3. Do not prepare or apply over asphalt, metal, or wood.

INSTALLATION

FLOOR DESIGN

1. Optimum ambient temperature range for application is 45°F-85°F. If temperature is outside of this ideal range, temperature should be adjusted with heaters or air conditioners. Substrate temperature should be $\geq 5^{\circ}\text{F}$ above the dew point.
2. If desired, a cove base should be installed prior to the floor according to the proper specifications for the coving material.
3. DO NOT Featheredge. Anchor free edges by placing a key way in the base concrete and at least 6" from edge.
4. Expansion joints need to be honored at all times. Create joints between dissimilar materials, around load-bearing columns, and to separate areas subjected to extreme thermal or mechanical stresses. After POLYQuik® Mortar is cured, honor these joints by sawcutting and filling with POLYQuik® CJS.
5. Moving control joints or cracks must be honored and properly prepared. Applying POLYQuik® Mortar over properly prepared and filled joints or cracks can result in the finished floor.

PRIMING

1. For most applications, priming is not required. If priming is required, contact your WVCO Representative for priming instructions.

MIXING

1. DO NOT mix by hand. Use a mechanical mixer with a dispersing blade (no spiral blades) between 800-1000 RPM. Only mix full kits.
2. Thoroughly premix pigment, Part A, & B with a drill and paddle or concrete mixer until a uniform color is achieved.
3. Slowly add the bag of solids and scrape container sides while mixing and ensure all solids are wetted out.
4. Apply to floor immediately by pouring over the surface. Do not completely empty mixing container on floor by leaving container upside down and do not scraping the container to remove all of the material.

APPLICATION

1. POLYQuik® Mortar should only be applied by trained professionals.
2. Immediately spread mixed material on substrate in a ribbon line then $\frac{1}{2}$ " gage rake or $\frac{1}{2}$ " notched squeegee and trowel the material in one direction to the desired thickness. Excess raking or troweling will cause smooth areas, a resin rich surface, and other surface defects.
3. If necessary, immediately back roll with a loop and spike roller to remove trapped air. Do not walk on finished floor with spike shoes to avoid creating pinholes. Do not use power trowels, power floats, serrated hand trowels, or screed boxes. Apply more material within 15 minutes to create a continuous, seamless floor.
4. If required, evenly apply aggregate to surface within 15 minutes of application and at 1lb per square foot.
5. Allow to cure 8 hrs (@ 72°F) prior to foot traffic or sweeping aggregate and 16 hrs prior to wheel traffic.
6. If required, topcoat with POLYQuik® P-690/695 after a minimum of 48 hours after application following POLYQuik® P-690/695 technical data sheet instructions.
7. Proper application is the responsibility of the user. Field visits by WVCO Representative are for the purpose of making technical recommendations only and not for supervising or providing quality control on the jobsite.

CLEANING & MAINTENANCE

Wash tools with acetone or POLYQuik® Cleaner immediately after use. Observe all precautions when handling these solvents. Cured material must be removed mechanically.

HEALTH AND SAFETY

Willamette Valley Company recommends reading and becoming familiar with the MSDS before using this product.

DISCLAIMER OF WARRANTY

TEST RESULTS ARE TO BE CONSIDERED AS REPRESENTATIVE OF CURRENT PRODUCTION AND SHOULD NOT BE TREATED AS SPECIFICATIONS. WHILE ALL THE INFORMATION PRESENTED IN THIS DOCUMENT IS BELIEVED TO BE RELIABLE AND TO REPRESENT THE BEST AVAILABLE DATA ON THESE PRODUCTS, NO GUARANTEE, WARRANTY, OR REPRESENTATION IS MADE, INTENDED, OR IMPLIED AS TO THE CORRECTNESS OR SUFFICIENCY OF ANY INFORMATION, OR AS TO THE SUITABILITY OF ANY CHEMICAL COMPOUNDS FOR ANY PARTICULAR USE, OR THAT ANY CHEMICAL COMPOUNDS OR USE THEREOF ARE NOT SUBJECT TO A CLAIM BY A THIRD PARTY FOR INFRINGEMENT OF ANY PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT. EACH USER SHOULD CONDUCT A SUFFICIENT INVESTIGATION TO ESTABLISH THE SUITABILITY OF ANY PRODUCT FOR ITS INTENDED USE.

PROPER APPLICATION IS THE RESPONSIBILITY OF THE USER. AS WITH ANY PRODUCT THE USE OF THIS PRODUCT IN A GIVEN APPLICATION MUST BE TESTED (INCLUDING BUT NOT LIMITED TO FIELD TESTING) IN ADVANCE BY THE USER TO DETERMINE SUITABILITY. TESTING IS THE REQUIREMENT OF BOTH ENGINEERS AND CONTRACTORS ALIKE. WVCO DOES NOT WARRANT THE APPLICATION UNDER ANY OR ALL CIRCUMSTANCES.

WILLAMETTE VALLEY COMPANY

www.wilvaco.com
info@wilvaco.com

DIVISIONS

WESTERN DIVISION

1075 Arrowsmith Street
PO Box 2280
Eugene, OR 97402
Tel 541.484.9621
www.POLYQUIK.com
www.SPIKEFAST.com

EASTERN DIVISION

6662 Marbut Road
Lithonia, GA 30058
Tel 888.878.9826

MIDWEST DIVISION

1549 Hwy 2
Two Harbors, MN 55616
Tel 218.834.3922

PRECISION TECHNOLOGIES DIVISION

675 McKinley Street
Eugene, OR 97402
Tel 541.484.2368
www.pre-tec.com

SOUTHERN DIVISION

100 Dixie Mae Drive
PO Box 4450
Pineville, Louisiana 71361
Tel 318.640.5077

SUBSIDIARIES

CANADIAN WILLAMETTE

325 Edworthy Way
New Westminster BC V3L 5G4
Tel. 800.663.4298

ECLECTIC PRODUCTS INC.

Corporate Office
1075 Arrowsmith Street
Eugene, OR 97402
Tel 541.284.4667
www.eclecticproducts.com

IDAHO MILL & GRAIN

445 North 430 West Hwy
Po Box 188
Malad City, Idaho 83252
Tel 208.766.2206

TAPEL WILLAMETTE LTD. S.A.

Av. Estero La Posada 3625 Parque
Industrial Coronel Coronel, Chile
Tel 011.56.41.928.100
www.tapel.cl

