

Technical  
Data Sheet



Willamette Valley Company

www.wilvaco.com

800.333.9826

Partnering through service,  
innovation, and integrity

# POLYQuik® FastPatch SC

## Flexible Spall Repair

### DESCRIPTION

POLYQuik® FastPatch SC is a flexible, two-component urethane designed as a fast curing repair product for concrete. It is 100% solids product supplied in ready-to-use kits. FastPatch SC has excellent adhesion to concrete. Concrete repaired with FastPatch SC can be opened to traffic in as little as 1 hour.

### WHERE TO USE

- **Roadways**—repair cracks, spalls, broken slabs
- **Parking Lots**—repair damaged areas
- **Warehouses**—transitions or spalls
- **Sidewalks**—broken or damaged areas

### FEATURES AND BENEFITS

- **Cold Applied**—easy to use and safe to apply
- **Fast Curing**—reopen to traffic quickly
- **Flexible**—absorbs impact and stress
- **Excellent Adhesion**—restores damaged areas

### PACKAGING

5-gallon kit  
High Yield Kit

### COLORS

Gray

### YIELD

5-gallon kit = 1.25 gal resin mixed (0.167ft<sup>3</sup>).  
With sand volume = 1.95 gal (0.26ft<sup>3</sup>)

High Yield Kit = 3.75 gal resin mixed (0.5ft<sup>3</sup>).  
With sand volume = 5 gal (0.66ft<sup>3</sup>).

### SHELF LIFE

1 year when properly stored.

### STORAGE

Store and ship this product in a clean, dry, low-humidity, shaded or covered environment at 60-90° F (15-32° C).

## TECHNICAL INFORMATION

### Typical Properties

<b>Hardness, Shore A, ASTM D 2240</b>	85
<b>Potlife, minutes, 70° F (21°C)</b>	5
<b>Service temperature, ° F (° C)</b>	10 – 170 (-12 - 77)
<b>Viscosity, cps, ASTM D 4878, aggregate included</b>	7,000
<b>VOC, lbs/gal (g/L), ASTM D 2369</b>	0

### Processing Parameters

<b>Ratio by volume</b>	4 to 1 (resin to ISO)
<b>Application temp, ° F (° C)</b>	50 to 100 (10 to 37)
<b>Application method</b>	Mechanical mix & pour
<b>Recommended thickness</b>	> 1/4"

## APPLICATION

### SURFACE PREPARATION

#### CONCRETE

1. The concrete surface being repaired must be fully cured 28 days, structurally sound (200psi or greater according to ASTM D7234), clean (ASTM D4258), and dry (less than 5%, ASTM E1907).
2. Concrete surface must be dry and clean. Water or oil present can result in poor adhesion. Apply product only if surface temperature is 5° F (3° C) above the dew point to avoid application over damp surface.
3. Remove any contaminants before profiling surface.
4. It is recommended to profile surface according to ICRI Guide 03732 to a minimum of CSP 3 by abrasive blasting.
5. Saw cut spall area in shape of a square 1-3 inches (2.54-7.6 cm) deep, hammer (15 lb) spall area and remove debris. Recommended repair size is less than 16 ft<sup>2</sup> (1.49m<sup>2</sup>).
6. Use a minimum 120 PSI continuously dry compressed air to blow out loose debris, dirt and dust prior to applying product. Moist concrete can be torched dry. If moisture returns immediately after torching, stop and do not install FastPatch in this area.
7. Use a steel bristle brush to remove dirt on vertical and horizontal concrete surfaces and use compressed air to blow out prior to applying product.
8. As necessary, plug all gaps or joints surrounding the spall area with foam backer rod and choose a rod width that fits tightly in the area.
9. Priming all concrete surfaces is recommended. Prime with POLYPrime or contact WVCO for proper primer selection. Refer to primer TDS sheets for detailed instructions.
10. For spall areas, honor all joints or moving cracks in the spall area by saw-cutting after FastPatch has cured.

#### OTHER MATERIALS

1. Previously installed polymer materials must be tested to determine the best method of preparation to achieve acceptable adhesion. Consult manufacturer for recommendations. Typically, methods will include solvent cleaning, abrading, and vacuuming surface.
2. FastPatch is not typically recommended for use in asphaltic roadways. Exceptions do occur; contact Willamette Valley Co. for more details.
3. Avoid placing FastPatch on asphaltic materials, bare ground, dirt, grass or other non-structural surfaces.

### PROCESSING

1. Precondition Kits to 70°F (21°C) for 24 hours before use.
2. Kits can be heated up to 100°F (38°C) to speed cure at colder temperatures. It is recommended to heat all components when the surface temperature is below 50°F (10°C).
3. Check that primed surfaces are ready for application of FastPatch before applying mixed material.
4. Ensure that the mixing station is a short distance from the application area. Multiple kits can be mixed at the same time when repairing large or multiple repairs.
5. Use entire kit and do not divide.

6. Attach a clean mixing blade with a width 1/3 the diameter of the mixing container to a 500RPM drill.
7. POTLIFE IS LESS THAN 5 MINUTES. USE IMMEDIATELY AFTER MIXING.

### APPLICATION

1. Protect the surfaces around the application area to prevent contamination during the installation.
2. Prime all surfaces.
3. **5-gallon Kits** - Remove the two containers from the 5-gallon bucket (1 gal – resin, 0.25 gallon – iso), while leaving the sand. Shake the 1-gallon resin container for 30 seconds and pour the contents into the mixing bucket with the sand. Continue at Application Step 5.
4. **High Yield Kits** – Gather bagged sand, resin pail and jug of iso.
5. Mix the sand and resin together for 30 seconds or until the sand is completely wetted out by the resin.
6. Add the iso to the filled bucket and mix the material together for 30 seconds. Scrape the SIDES and BOTTOM of the bucket with a straight edge and continue to mix for an additional 30 seconds. All of the iso must be thoroughly incorporated in the resin before adding it to the spall. THE MATERIAL MAY NOT SET-UP IF IT IS IMPROPERLY MIXED. Signs of poor mixing include dark swirls and tacky material that does not solidify.
7. Pour the material into the desired concrete spall and shape using a plastic trowel.
8. Add topping sand as necessary when the material has gelled. Add topping sand to refusal.

NOTE: Material is typically ready for traffic in 1-hour at 70°F (21°C). Colder temperatures and cold gravel will slow the cure. Warmer temperatures will speed the cure.

SKID RESISTANCE: It is the responsibility of the Applicator to ensure the product meets the minimum skid resistance requirement. Refer to the Agency or End-user friction management policy or specifications to determine the minimum skid resistance and test method requirement. Aggregate (Sand, pumice, flint) can be added topically at the gel stage or Fastpatch can be ground, sanded or abraded to achieve any necessary skid resistant texture.

Temp.	Pot Life	Estimated Return to Service (min.)
101	> 4	30
72	5	60
52	8	90

### CLEANING & MAINTENANCE

Clean equipment with POLYQuik® Cleaner or acetone immediately after use. Cured material must be removed mechanically.

## HEALTH AND SAFETY

Before handling, you should become familiar with the Material Safety Data Sheet (MSDS) regarding the risks and safe use of this product. To obtain an MSDS please call 800 333 9826 or send an email to: [msds@wilvaco.com](mailto:msds@wilvaco.com).

### DISCLAIMER OF WARRANTY

TEST RESULTS ARE TO BE CONSIDERED AS REPRESENTATIVE OF CURRENT PRODUCTION AND SHOULD NOT BE TREATED AS SPECIFICATIONS. WHILE ALL THE INFORMATION PRESENTED IN THIS DOCUMENT IS BELIEVED TO BE RELIABLE AND TO REPRESENT THE BEST AVAILABLE DATA ON THESE PRODUCTS, NO GUARANTEE, WARRANTY, OR REPRESENTATION IS MADE, INTENDED, OR IMPLIED AS TO THE CORRECTNESS OR SUFFICIENCY OF ANY INFORMATION, OR AS TO THE SUITABILITY OF ANY CHEMICAL COMPOUNDS FOR ANY PARTICULAR USE, OR THAT ANY CHEMICAL COMPOUNDS OR USE THEREOF ARE NOT SUBJECT TO A CLAIM BY A THIRD PARTY FOR INFRINGEMENT OF ANY PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT. EACH USER SHOULD CONDUCT A SUFFICIENT INVESTIGATION TO ESTABLISH THE SUITABILITY OF ANY PRODUCT FOR ITS INTENDED USE. PROPER APPLICATION IS THE RESPONSIBILITY OF THE USER. AS WITH ANY PRODUCT THE USE OF THIS PRODUCT IN A GIVEN APPLICATION MUST BE TESTED (INCLUDING BUT NOT LIMITED TO FIELD TESTING) IN ADVANCE BY THE USER TO DETERMINE SUITABILITY. TESTING IS THE REQUIREMENT OF BOTH ENGINEERS AND CONTRACTORS ALIKE. WVCO DOES NOT WARRANT THE APPLICATION UNDER ANY OR ALL CIRCUMSTANCES.

## WILLAMETTE VALLEY COMPANY

[www.wilvaco.com](http://www.wilvaco.com)  
[info@wilvaco.com](mailto:info@wilvaco.com)

### DIVISIONS

#### WESTERN DIVISION

1075 Arrowsmith Street  
PO Box 2280  
Eugene, OR 97402  
Tel 541.484.9621  
[www.POLYQUIK.com](http://www.POLYQUIK.com)  
[www.SPIKEFAST.com](http://www.SPIKEFAST.com)

#### EASTERN DIVISION

6662 Marbut Road  
Lithonia, GA 30058  
Tel 888.878.9826

#### MIDWEST DIVISION

1549 Hwy 2  
Two Harbors, MN 55616  
Tel 218.834.3922

#### PRECISION TECHNOLOGIES DIVISION

675 McKinley Street  
Eugene, OR 97402  
Tel 541.484.2368  
[www.pre-tec.com](http://www.pre-tec.com)

#### SOUTHERN DIVISION

100 Dixie Mae Drive  
PO Box 4450  
Pineville, Louisiana 71361  
Tel 318.640.5077

### SUBSIDIARIES

#### CANADIAN WILLAMETTE

19081- 27<sup>th</sup> Avenue  
Surrey BC V3S 5T1  
Tel. 800.663.4298

#### ECLECTIC PRODUCTS INC.

Corporate Office  
1075 Arrowsmith Street  
Eugene, OR 97402  
Tel 541.284.4667  
[www.eclecticproducts.com](http://www.eclecticproducts.com)

#### IDAHO MILL & GRAIN

445 North 430 West Hwy  
Po Box 188  
Malad City, Idaho 83252  
Tel 208.766.2206

#### TAPEL WILLAMETTE LTD. S.A.

Av. Estero La Posada 3625 Parque  
Industrial Coronel Coronel, Chile  
Tel 011.56.412.928.100  
[www.tapel.cl](http://www.tapel.cl)

